

installing iGlaze

1



slowly peel off the backside clear film to expose the adhesive.

2



with the top-side clear film still intact, carefully align iGlaze with all four sides of your iPod. do not press hard on iGlaze until you feel there's a perfect alignment.

3



if not aligned properly, peel iGlaze off starting from the side gently, then repeat step 2.

4



remove the top-side click wheel film, you've now transformed your iPod.

***save your clear film and foam tray for future storage of your iGlaze.**

removing iGlaze:

note: please understand that iGlaze is made of rigid material, hence bending it with too much force will create creases between the layered films or may even result in breaking it. please follow the step-by-step instructions below and NEVER try to pry off iGlaze from the top or the bottom:





using your finger, gently pry loose iGlaze starting from the side near where the click wheel is.



slowly raise iGlaze off with consistent force along the side. DO NOT bend iGlaze with excessive force. gently pry off the iGlaze click wheel and center button protectors in the same manner.



for safe-keeping, place the adhesive side of iGlaze back onto the original clear film.



store iGlaze in the original foam tray and keep it away from direct sunlight. by doing so the adhesive should remain sticky the next time you re-apply iGlaze.