


# FREEstyle

Clip-On rear view mirror hands-free system with unique built in record facility

## Illustrated User Guide



### Contents

1. FreeStyle™ mirror unit, complete with microphone
2. Power/Phone Lead
3. JMC Metallic Strips (x2) with alcoholic wipe
4. Self-Adhesive Dash-Mount Magnet
5. Cable Clips
6. User Guide

## Controls and Features



### Controls

**Power** – For internal battery only (Not applicable to UK model).

**Mute** – Switches off loud-speaker, allowing private conversation when using optional ear-piece.

**Send** – Performs the function of the answer/dial button on your handset (Not applicable to all models).

**Rec** – Activates 64 second digital recording facility (self overwriting)

**Play** – Playback your digital recording

**Mic** – Microphone Sensitivity control.

*Hint: This should be set as low as possible to eliminate background noise/feedback. Please TAKE NOTICE that this is NOT the volume control, high settings will NOT increase volume, but can have a negative effect on the call quality due to microphone oversensitivity.*

**SP** – Controls the volume of FreeStyle's™ loud-speaker.



### Connections

**Ear** – Ear-Piece socket. You can connect a standard 2.5mm headset/earpiece into this socket for private conversation(see Mute control). Ear-Piece/Head-Set not included.

**Power** (on underside of unit) – For use with internal battery (Not applicable to UK model)

**Phone** – Connect the Power/Phone Lead into this socket.

**Power** – Connect the Power/Phone Lead into this socket.

**Microphone** – To be clipped onto your sun-visor.



### Display

**Power LED** – Green LED will be illuminated when HassleFree is connected to your Cigarette Lighter.

**Mute LED** – Green LED will be OFF during normal operation. Will illuminate when Mute/ear-piece mode is in use.

**Power Level** – 4 x Red LED; Indicates Power Level

**Rec/Play LED** – LED will illuminate RED during recording, and GREEN during playback

## Installation - Mirror Unit



On the back of the FreeStyle™ unit you will see two pairs of clips



Place the bottom pair of clips onto the underside of your existing rear view mirror.



Lift the unit so that the bottom clips extend allowing the top clips to be fixed into position on the top edge of your rear view mirror.



Select a suitable position for the Microphone. This should be placed close to the user's head – the driver's sun-visor is normally adequate.



Connect the power and phone lead into their respective sockets on the top edge of FreeStyle™



The Power/Phone Lead should be secured and hidden into the vehicle's interior using the seals or joins around the windscreen and door "A-Frame" and under your dashboard.



Ensure that you leave yourself enough cable to be able to connect to your cigarette lighter and to your handset in its intended location.



Connect your Power Lead (from the Power/Phone Lead) into your cigarette lighter socket. Some LED's will light up on the front of the kit to indicate that it has power.

## Installation – Dash-Mount Magnet



Clean the selected area thoroughly with the alcoholic wipe provided, and then allow surface to air dry.



Peel off the backing from the magnet and place firmly onto your dashboard.

## Mounting your handset onto the Dash-Mount Magnet

Try placing your handset onto the magnet's surface, and if you do not feel a magnetic pull it simply means that your phone has no metal content.



If this is the case, simply clean the appropriate area on the back of your handset with alcoholic wipe provided.



After allowing the phone's surface to air-dry, secure to it one of the Metallic Strips provided. The Dash-Mount Magnet will now hold your handset securely.

## Connecting your handset to FreeStyle



FreeStyle™ is made with a standard 2.5mm jack plug connection. This connection can be used directly with certain types of phones (e.g. Motorola Time-Port, Samsung A300, Sharpe GX10)



For most phones you will require an audio adaptor to allow connection to FreeStyle™. Should you change your phone at a later date you only need to change your adaptor, rather than the entire kit.

To connect via an Audio Adaptor simply plug the Phone Lead into the socket on the Adaptor, and plug the adaptor into the hands-free/ear-piece socket on your phone.

*Hint: There are some models of phones with which the 2.5mm connection will fit but not function correctly. Although some phone manufacturers use a standard size, they use their own specialised connections meaning that an adaptor is still required (e.g. Nokia 3000 and 8000 series, Samsung T100, Nokia 7650)*

## Adjusting FreeStyle's™ settings to suit your phone

FreeStyle™ offers you full control over the Audio settings to suit your phone, vehicle and personal preference.

Once you have installed your unit you should make a test call to a friend/colleague on a land line so that they can assess the inbound and outbound speech. **Safety Notice: These adjustments should be made with the vehicle parked.**



Adjust the Speaker Volume setting to suit, remembering that your mobile phone probably has its own speaker volume setting which you can also use to adjust/improve volume and/or sound quality.



Microphone Sensitivity should be set as low as possible so as to eliminate background noise and/or feedback. Having this set too high may have a detrimental effect on the quality of outbound speech.

*Please Note that this is NOT the volume control, high settings will NOT increase volume, but can have a negative effect on the call quality due to microphone oversensitivity.*

When you and your caller are satisfied with the volume and quality of sound you can hang up, and you're ready to go!

## Digital Recording

Drive HassleFree™ features a digital record facility which allows you to record either a memo to yourself, or a 2-way conversation whilst the hands-free facility is in use. This is particularly useful for noting memos such as directions, addresses or phone numbers.



Simply press the Rec button to start recording, and again to stop your recording. This facility is self-overwriting. A red LED will display on Drive HassleFree™ during recording.

You can playback your recording as many times as you wish.



Press the Play button to start playback, and again to stop. A green LED will display on Drive HassleFree™ during playback.

## Mute / Privacy Mode

By pressing the Mute button you can deactivate the loud speaker.

A small Green LED will illuminate on the front of Drive HassleFree™ when Mute mode is active.

Whilst in mute mode you can connect a standard 2.5mm earpiece or headset (not supplied) into the socket marked Ear, which will allow you to hold a private call.